

Diesel Spare Parts Suitable for MAN B&W L60MC/L60MCE

We can supplying following spare parts which are suitable for L60MC/L60MCE:

NO.	PART NAME	PART NO.		REMARK
		MITSU	GENUINE/HITACHI /others	
1	Main bearing shell, complete	111A-B	91210-132-108	new
2	cooling jacket assy.	231A-B	90302-52-142;90302-37K-K022&90302-37K-K034	new
3	O-ring for cylinder liner	231A-b7; 231A-B11; 231A-B12	046;90302-52-154, 90302-52-034; 90302-52-	new
4	Non-return valve on cyl. Liner	231A-BA	90302-52-058	new
5	cylinder liner	231A-C1	90302-52-129/90302-37K-K034	new/used
6	Crosshead bearing shell, complet	311A-3	90401-32K-392/90401-98-260	recondition
7	crosshead	311A-A1	90401-32K-247/90401-55-247	new
8	piston rod & stuffing box	332A	90201-67; 90205-50	new
9	piston crown	332A-1	90201-67-072	recondition
10	lock washer on piston	332A-17	90201-67-023	new/used
11	piston skirt	332A-2	K118	new/used
12	piston ring, right	332A-5	90201-67-059; 90201-39-059/902-3	genuine new
13	piston ring, opposite	332A-6	90201-67-060; 90201-39-060/902-4	new
14	piston ring	332A-7; 332B-7		genuine new
15	stuffing box assy.	332A-A	90205-50; 90205-30K	used
16	stuffing box parts- Top compression ring	332A-AB	90205-30A-H001; 90205-94-25	genuine new
17	stuffing box part-- Cross sealing ring Groove for items 025, 027 and 040	332A-AB2; AC2; AD2	90205-94-204	new
18	stuffing box parts-- Back sealing ring	332A-AC; 332A-AD	90205-94-037	new
19	stuffing box parts-- Cross sealing ring	332A-AE	90205-94-049/90205-50-086	genuine new
20	stuffing box parts-- Inserts for compression ring	332A-AF	90205-94-157; 90205-30A-H002	new
21	stuffing box part-- Cross sealing ring	332A-AF2; AG2	90205-94-216	new
22	stuffing box parts-- Inserts for compression ring	332A-AG	90205-30A-H003	new
23	stuffing box parts-Scrapper ring	332C-B/F/G	90205-94-194; 90205-50-169	new
24	stuffing box parts-Sealing ring	332C-C/D	90901-145-400	new
25	cylinder cover	341A-A1	90101-30K	new/used
26	Stud with guide face for fuel valv	341A-C2	90101-30K-283	new/used
27	Stud for fuel valve	341A-C3	90101-30K-295	new/used
28	spring housing complete on cyl. C	341A-CA	90101-30K-209	new/used
29	Stud f. starting valve	341A-D1	90101-30K-043	new/used
30	Nut on cylinder cover	341A-D3	90101-30K-031	new/used
31	hydraulic ring for cyl. Cover	341B-1	90102-22-013	new/used
32	inner nut & outer nut hydr. Ring	341B-2&341B-3	90102-22-049&90102-22-133/90102-22-145	new/used

OCEAN POWER ENGINEERING CO.,LTD
sales@marine-servicesolution.com www.marine-servicesolution.com
NO.614 .Caoyang Road ,Putuo District, Shanghai Tel:0086-21-60723303 Fax:0086-21-35325082

Diesel Spare Parts Suitable for L60MC/L60MCE
We can supplying following spare parts which are suitable for L60MC/L60MCE:

NO.	PART NAME	PART NO.		CONDITION
		MITSU	GENUINE/HITACHI/others	
33	cooling water connection pipe	341C-1	90101-30K-114	new/used
34	cooling water connection flange	341C-2	90101-30K-080	new/used
35	exhaust valve	343A	90801-78/90801-52K	new/used
36	exhaust valve seat	343A-12	90801-78-875;90801-52K-875	recondition
37	exhaust valve o-ring and sealing ring	343A-13;14;21;22;33;67;68		new
38	Safety valve on exh. Valve	343A-27	90801-78-373	new
39	non-return valve on exhaust valve	343A-28	90801-52K-K718;90801-78-718/EN206A10,105	new
40	liner for spindle guide on exhaust valve	343A-3	90801-78-324;90801-52K-336	new
41	exhaust valve guide ring	343A-35	90801-78-013;90801-52K-013	new
42	piston on exhaust valve	343A-43	90801-78-731	new
43	piston ring on exhaust valve	343A-44	90801-52K-706	new
44	Cooling water connection on exhaust valve	343A-73	90801-52K-899	new/used
45	exhaust valve spindle complete	343A-B	90801-78-826	recondition
46	throttle valve on exhaust valve	343A-C	90801-52K-216	new
47	fuel valve	344A	90910-44/90910-31K	new/used
48	fuel nozzle	344A-1	90910-44-041/90910-31K-K041	DISPA new
49	fuel valve holder	344A-2	90910-83-028;90910-44-053	used
50	fuel valve spindle guide complete	344A-A	148	new
51	fuel valve thrust spindle	344A-B1	90910-83-185	new
52	fuel valve Disc(Optional extras)	344A-B5	90910-83-962/90910-44-124/90910-31K-124	new
			90913-22-276	
54	starting valve	346A	90704-30	new/used
55	Safety valve, complete	347A	91101-20-117;91101-15K-010/911-1;91101-31-117	new
56	exhaust roller guide complete on valve gear	431A-C	90805-62-015/90805-44K-15	used
57	Fuel pump roller guide, complete	431A-D	705/90902-127-012	used
58	fuel pump	433A	90901-66/90901-52K	new/used
59	fuel pump top cover	433A-3	90901-66-365	new
60	pump barrel assy./plunger with barrel	433A-BA	90901-66-507;90901-52K-507/909-41	new
61	suction valve assy.	433A-C1	90901-52K-436/909-44	new
NO.	PART NAME	PART NO.		QUALITY
		MITSU	GENUINE/HITACHI/others	
62	fuel pump spring guide	433A-C4	90910-83-089	new
63	exhaust high-	434B-A		used/new
64	exhaust valve gear	434C	90805-62; 90805-44K	used
65	piston on exh. Valve gear	434C-2	90805-62-184	new/used
66	Nonreturn valve on main starting valve	445A-4	90702-18K-757	new/used
67	Indicator valve	453A-27	90612-62-447	new/used

