

We can supplying following spare parts which are suitable for L80MC/L80MCE:

No.	PART NAME	PART NO.		QUALITY
		KAWASAKI	MITSU	
1	cylinder cover	90101-30K-055	341A-A1	used/genuine new
2	nut and stud on cylinder cover	031/187/199/210/205	341A-B;B1;B2;C2;C3;C5;D; D1;D3	used
3		90101-30K-209		
4	spring housing complete on cyl. Cover	90101-30K-209	341A-CA	used
4	hydraulic ring	90102-16K-013	341B-1	genuine new
5	Piston ring sets	90201-139-	332B-5/332B-6	genuine/new
		084/096/106/118; 90201-40K-059/060		
6	piston and piston rod	90201-40K	332B	used
7	piston crown	90201-40K-072	332B-1	used
8	piston skirt	90201-40K-K118	332B-2	used
9	piston rod stuffing box parts (scraper ring, sealing ring, base ring, spring, etc.)	90205-32k-k004~K019	332C	new
10	cooling jacket	90302-38K-010	231F-2	used
11	cylinder liner	90302-38K-K046	231F-1	used/genuine new
12	non-return valve, complete	90302-38K-105	231F-A	used/genuine new
13	cylinder liner parts (pipe, flange, intermediate piece, lifting screw, distance plate, etc.)	90302-38K-117/130/K178/K225/K228	231F	used
14		lubricator		
15	plunger assy. On lubricator		451H-AD	genuine new
16	thrust piece for connection rod & cross head	90401-35K-164	311A-11	genuine new
17	crankpin bearing shell	90401-35K-296	311A-5	genuine new/used
18	crosshead bearing shell	90401-35K-392	311A-3	genuine new
19	cam shaft bearing shell in 2/3	90610-44k-076	232A-H3	genuine new
20	thrust ring for cam bearing shell	90610-44K-243	232A-H4	genuine new
21	exhaust cam	90611-52K-095	411A-B1	used
22	Indicator valve complete and parts	90612-14-K447;90612-47-447	453A-27	used

OCEAN POWER ENGINEERING CO.,LTD
 sales@marine-servicesolution.com www.marine-servicesolution.com
 NO.614 .Caoyang Road ,Putuo District,Shanghai
 Tel:0086-21-60723303 Fax:0086-21-35325082

Attn. Technical Dept./ Purchasing Dept.
We can supplying following spare parts which are suitable for L80MC/L80MCE:

No.	PART NAME	PART NO.		
		KAWASAKI	MITSU	
23	starting valve complete and parts	90704-20K	346A	used
24	exhaust valve	90801-54K	343A	used
25	exhaust valve housing	90801-54K-838	343A-A1	used
26	exhaust valve spindle	90801-54K-826	343A-B	genuine new/used
27	exhaust valve bush/liner for spindle guide	90801-54k-324	343A-3	genuine new
36	piston on exh. valve gear	90805-45K-184	434C-2	genuine new/used
37	High-pressure pipe, complete(between exh.valve and oil cylinder)	90806-56-308 308.00806-15L-308		used
38	fuel pump	90901-53K	433A	used
39	suction valve, complete	90901-53K-436	433A-C	used/new
40	pump barrel complete with plunger	90901-53k-507	433A-B	genuine new
41	oring and sealing ring on fuel pump	90901-53K-377/424/581	433A-5/B4/B7/BA4/C5/C6/F13/G2	new
42	spring, internal & external on fuel pump gear	90902-32K-2848-106	433A-F3&433A-F4	new
43	fuel pump roller guide, complete	90902-32K-705	431A-D	used
44	shock absorber, complete	90904-02K-049		used
45	fuel valve	90910-35K	344A	used
46	nonreturn valve complete on fuel valve	90910-35K-197	344A-C	genuine new
47	thrust spindle spindle complete on fuel valve	90910-35k-207&219&220	344A-B	genuine new
48	nozzle	90910-73-016; 90910-37K-016	344A-1	genuine new/ OMT new